


Take note:

- ! When removing stains, the fabric should not be rubbed vigorously.
- ! To avoid ring formation, rub with a clean absorbent cloth from the edge towards the centre of the stain.
- ! Small stains can usually be removed by light dabbing with a moist brush or sponge.
- ! Take care to keep the fabric moist rather than wet.
- ! Spot removal is only worthwhile for small stains. In cases of intensive and general soiling, whole cushions should be cleaned.
- ! It is essential that fabrics are left to dry completely – do not apply heat.
- ! Underlying materials may deteriorate by the cleaning process.

Spot and Stain Removal Guide



All-purpose adhesive	8	Fruit 2 possibly	13 + 9	Red wine	1 possibly 13 + 10
Ball Pen	7	Fruit juices 1 possibly	13 + 9	Shoe dye	3
Beer	1	Furniture polish	5	Shoe polish	2 + 3
Blood	2	Glue	2	Skin cream	3
Butter	3	Hair tonic	7	Soil	1
Candle wax	4	Honey	2	Sparkling wine	1
Carbon paper	7	Ice-cream	1	Synthetic resin paint	10
Chalk	2	Ink	1 + 13 + 9	Starch	2
Chocolate	2 possibly 3	Lacquer (colourless)	3 possibly 6 or 10	Stock stains	1 possibly 9
Coffee	1 possibly 13 + 9	Lipstick	3 possibly 13 + 9	Street dirt	2
Coloured pencils	3	Machine oil	3	Talcum powder	2
Contact adhesive	9	Make-up	2 or 3	Tea	1 possibly 13 + 9
Cream	2 + 3	Nail varnish	6	Tobacco	2
Duplicating ink	7 possibly 9	Oil	3	Varnish	3
Fat	3	Oil paint	5 possibly 10	Vegetable fat	3
Floor polish	3	Perfume	7	Water colour	1 possibly 9
Flower stains	7	Printer's ink	12 possibly 9	Wine	1 possibly 13 + 9

1. Use a moist rag; if necessary treat with dry foam according to the manufacturer's specification. Repeat if necessary.
2. As for [1]. If stains contain a lot of encrusted material, this should first be loosened by light scraping followed by vacuum cleaning.
3. Dry stains should be carefully cleaned with a solvent by rubbing lightly, always from the edge of the stain towards the centre.
4. Carefully scrape off solid stains, and then treat with solvent as suggested under [3].
5. Dab with turpentine (flammable!), and then remove stain carefully with solvent as suggested under [3].
6. Dab with acetone (flammable!). Always rub from the edge of the stain towards the centre.
7. Dab with alcohol (methylated spirit), and then possibly also with a solvent as suggested under [3].
8. As suggest under [6], but treat with ethyl acetate.
9. Dab with chlorine bleach (approximately 1 tablespoon per litre of water) and then rinse with clean water.
10. Remove stain with synthetic thinners (flammable!) and then treat with dry foam [1].
11. Soak with ethyl acetate/xylene 1:1 (flammable!) and soak up with a dry cloth. Repeat if necessary.
12. Dab with toluene (flammable!), then treat with soft soap and solvent [3].
13. Dab with 3% hydrogen peroxide solution and rinse with clean water.



Smart Ergonomic Workspace Solutions

Karo Manufacturing (PTY) Ltd | www.karo.co.za | info@karo.co.za

